

Doping profile validation

Validation de la méthode de détermination des profils de dopage:

- application of the TLM resistance measurement method*
*Transmission Line Measurement : http://tuttle.merc.iastate.edu/ee432/topics/metals/tlm_measurements.pdf
- at levels deeper and deeper by etching (Reactive Ion Etching ,RIE) of the implanted silicon
- to determine the value of the profile of the resistivity within the implanted layer of silicon

J-L. Perrossier
CTU-IEF

d'après la méthode proposée par Francesca CHIODI
IEF Université Paris-Sud

Implanted sample

Échantillon avec implant



- **Implanted sample**

- **Ultrasonic cleaning** ⁽¹⁾

- Photoresist coating
- Photoresist opening
- Wet etching ⁽²⁾
- Al deposition
- Al Lift Off
- Profile measurement
- I-V measurement
- Reactive Ion Etching

n
times ⁽³⁾

1. Ultrasonic cleaning
 - Acetone, 5 mn
 - Isopropanol, 5 mn
 - Drying: GN_2
2. Wet etching (just 10 mn before introduction in the deposition vacuum chamber)
 - BHF 30-60s
 - Rinse DIW
 - Drying: GN_2
3. $n \geq t / 200\text{nm}$ Time $\geq n \times 7\text{ mn}$



Zone dopée
 $t = 1\mu\text{m}$

Substrat Si:
380um


Photoresist coating/Enduction de résine

S1813 / 4000 rpm / 30s

- Implanted sample
- Ultrasonic cleaning (1)
- Photoresist coating
- Photoresist opening
- Wet etching⁽²⁾
- Al deposition
- Al Lift Off
- Profile measurement
- I-V measurement
- Reactive Ion Etching

1. Ultrasonic cleaning
 - Acetone, 5 mn
 - Isopropanol, 5 mn
 - Drying: GN₂
2. Wet etching (just 10 mn before introduction in the deposition vacuum chamber)
 - BHF 30-60s
 - Rinse DIW
 - Drying: GN₂
3. $n \geq t / 200\text{nm}$ Time $\geq n \times 7\text{ mn}$

n
times⁽³⁾




Mask: Direct laser writing


Mask

• $W \gg L$ ($W/L \sim 2-3$)

• $L_i > t$



Layout on a 10mm square piece of silicon




Photoresist opening

- Implanted sample
- Ultrasonic cleaning ⁽¹⁾
- Photoresist coating
- **Photoresist opening**
- Wet etching ⁽²⁾
- Al deposition
- Al Lift Off
- Profile measurement
- I-V measurement
- Reactive Ion Etching

1. Ultrasonic cleaning
 - Acetone, 5 mn
 - Isopropanol, 5 mn
 - Drying: GN_2
2. Wet etching (just 10 mn before introduction in the deposition vacuum chamber)
 - BHF 30-60s
 - Rinse DIW
 - Drying: GN_2
3. $n \geq t / 200\text{nm}$ Time $\geq n \times 7\text{ mn}$

n
times⁽³⁾



Aluminium deposition : 300nm , Plassys

(immediatly after wet etching BHF 30-60s)


- Implanted sample
- Ultrasonic cleaning (1)
- Photoresist coating
- Photoresist opening
- Wet etching⁽²⁾

• Al deposition

- Al Lift Off
- Profile measurement
- I-V measurement
- Reactive Ion Etching

n
times⁽³⁾

1. Ultrasonic cleaning
 - Acetone, 5 mn
 - Isopropanol, 5 mn
 - Drying: GN₂
2. Wet etching (just 10 mn before introduction in the deposition vacuum chamber)
 - BHF 30-60s
 - Rinse DIW
 - Drying: GN₂
3. $n \geq t / 200\text{nm}$ Time $\geq n \times 7\text{ mn}$





Aluminium Lift Off

- Implanted sample
- Ultrasonic cleaning (1)
- Photoresist coating
- Photoresist opening
- Wet etching⁽²⁾
- Al deposition

• Al Lift Off

- Profile measurement
 - I-V measurement
 - Reactive Ion Etching
- n times⁽³⁾

1. Ultrasonic cleaning
 - Acetone, 5 mn
 - Isopropanol, 5 mn
 - Drying: GN₂
2. Wet etching (just 10 mn before introduction in the deposition vacuum chamber)
 - BHF 30-60s
 - Rinse DIW
 - Drying: GN₂
3. $n \geq t / 200\text{nm}$ Time $\geq n \times 7\text{ mn}$




Reactive Ion Etching of implanted silicon*

- Implanted sample
- Ultrasonic cleaning (1)
- Photoresist coating
- Photoresist opening
- Wet etching⁽²⁾
- Al deposition
- Al Lift Off
- Profile measurement
- I-V measurement
- **Reactive Ion Etching**

1. Ultrasonic cleaning
 - Acetone, 5 mn
 - Isopropanol, 5 mn
 - Drying: GN_2
2. Wet etching (just 10 mn before introduction in the deposition vacuum chamber)
 - BHF 30-60s
 - Rinse DIW
 - Drying: GN_2
3. $n \geq t / 200\text{nm}$ Time $\geq n \times 7\text{ mn}$

n
times⁽³⁾




*gravure RIE
enseignement
ou RIE AV
voir recette J-R.
Coudeville/X. Le
Roux

Reactive Ion Etching of silicon*

- Implanted sample
- Ultrasonic cleaning (1)
- Photoresist coating
- Photoresist opening
- Wet etching⁽²⁾
- Al deposition
- Al Lift Off
- Profile measurement
- I-V measurement
- **Reactive Ion Etching**

1. Ultrasonic cleaning
 - Acetone, 5 mn
 - Isopropanol, 5 mn
 - Drying: GN_2
2. Wet etching (just 10 mn before introduction in the deposition vacuum chamber)
 - BHF 30-60s
 - Rinse DIW
 - Drying: GN_2
3. $n \geq t / 200\text{nm}$ Time $\geq n \times 7\text{ mn}$


n
times⁽³⁾



*gravure RIE
enseignement
ou RIE AV
voir recette J-R.
Coudeville/X. Le
Roux


TLM method

I-V measurements
at one depth
for different
lengths



$$R = V/I$$

$R=f(L)$ at various depths




$$R = 2 R_c + R_l = 2 R_c + \rho_l \frac{L}{t_l W}$$

R_c : ohmic contact resistance of aluminium/silicon surface
 R_l : resistance of the layer between 2 contacts separated by a distance of l

Resistance in-depth measurement (TLM method) in trenches obtained by Reactive Ion Etching

$$R = 2 R_c + R_1 = 2 R_c + \rho_1 \frac{L}{t_1 W}$$



Example : etching steps of 200 nm in a sample with an implanted depth of 1μm

$$\rho_{sub} = (R_5 - 2 R_c) \frac{t_{sub} W}{L}$$

$$\rho_{800-1000} = \frac{(R_4 - 2 R_c) R_{sub}}{R_{sub} - (R_4 - 2 R_c)} \frac{W}{L} 200$$

....etc..